

## COMMENT RÉGLER LA TEMPÉRATURE DANS MA SUITE ?

ETAPE 1 : Repérer le boîtier qui se situe derrière votre porte d'entrée



ETAPE 2 : Insérer votre carte dans le boîtier



ETAPE 3 : Repérer le boîtier de la climatisation



ETAPE 4 : Cliquer sur l'icône entourée ci-dessous et régler la température de votre Suite à votre guise à l'aide du «+» ou du «-»



ETAPE 5 : Pour régler la vitesse de la ventilation (3 vitesses) cliquer sur l'icône ci-dessous et appuyer sur le «+» ou «-» pour définir la vitesse souhaitée.



IMPORTANT : Pour des raisons écologiques lorsqu'une porte ou fenêtre est ouverte, le système se met automatiquement en Mode Eco.



[RETOUR AUX GUIDES](#)





## HOW TO ADJUST TEMPERATURE IN MY SUITE ?

STEP 1 : Locate the case behind the front door



STEP 2 : Introduce your key card inside the case to switch on the light in your Suite.



STEP 3 : Locate the air-conditioning setting screen



STEP 4: Touch the icon circled hereinbelow and set the temperature as you please with «+» and «-»



STEP 5: Touch the icon circled hereinbelow to set the blow speed (3 levels) as you please with the «+» and «-».



WARNING: For some environmental reasons, the power-save mode will be automatically activate if a door or a window is open.



[BACK TO THE USER GUIDES](#)